CHILD RESTRAINT RECALL ANNOUNCEMENTS & SAFETY NOTICES | Revised 12/27/21

Most current changes are indicated with red arrow.



This list represents a quick reference tool displaying recalls, defects and safety notices for child restraints that are less than 10 years old. It has been established using information obtained from the Office of Defects Investigation, National Highway Traffic Safety Administration. Contact the car seat manufacturer for more detailed information.

For questions about the production of this list, contact Washington's Child Passenger Safety project manager at 253-447-3257 or velezc@ci.bonney-lake.wa.us

4MOMS (last recall 10/31/2016) Thorley Industries LLC, 912 Fort Duquesne Blvd, Pittsburgh, PA 15222 888-614-6667 www.4moms.com **Rear-Facing Only Seats**

Self-installing car seat model 1032 made 7/1/16–10/31/16 Problem: coupling hook may not properly engage, preventing carrier portion from securely attaching to base. In event of crash, carrier can detach, increasing risk of injury. While waiting for replacement 1. Double check carrier is properly locked into base by pulling up on carrier handle before every ride. 2. If carrier doesn't attach to base, use with carrier-only installation; or discontinue use until replacement received. Call 888-614-6667 or visit www.4moms.com/recalls with serial number to determine if affected and replacement carrier is needed.

ANGEL GUARD (No Recalls) 800-815-6330 x120, www.angel-guard.com

For Angel Ride car bed - see Merritt.

APRICA (No Recalls) 888-927-7422 www.aprica.com/enUS

BABY JOGGER, LLC. (last recall 4/30/2015) 4111 Premier Drive, High Point, NC 27265 800-241-1848 www.babyjogger.com

Rear-Facing Only Seats

City GO Infant Car Seats models BJ64510, BJ64529; Base models BJ80400, BJ61500; City Mini Carseat/Stroller model BJ72510; Vue Lite Carseat/Stroller model BJ70411, BJ70424, BJ70431 made 11/3/14- 4/30/15 Problem: incorrect or missing information on labels or instructions may cause incorrect use, increasing risk of injury to child. Call: 800-241-1848 for free replacement infant car seat.

BABY TREND INC. (last recall 7/23/2016) 1607 S Campus Ave, Ontario, CA 91761 800-328-7363 www.babytrend.com

3-in-1

Hybrid LX 3-in-1 Centennial booster seat model FB58181 made 7/23/16

Hybrid LX 3-in-1 Kiwi booster seat model FB48417 made 7/14/16

Problem: Center adjuster rivet may pull through or break if used with child over 40 lbs, putting child at risk of injury. Call: 1-909-773-0018 for seat replacement or full refund.

TrendZ Fastback 3-in-1 made 10/2011 - 7/2013 models FB60070, FB60408 Problem: May experience difficulty unlatching harness buckle; buckle may become stuck - increasing risk of injury if prompt exit of vehicle is required. Does not affect performance of car seat or buckle to restrain the child. Call: 800-328-7363 or visit www.babytrend.com for remedy kit.

BERGERON (No Recalls) 15 S Second Street, Dolgeville, NY 13329, 800-371-2778 www.adaptivemall.com

BRITAX (last recall 5/31/2017) 4140 Pleasant Road, Fort Mill, SC 29708, 888-427-4829, www.britaxusa.com

Rear-Facing Only Seats

B-Safe 35 made 10/1/14-7/1/15 Models: B-Safe 35 child seats E9LU65M, E9LU65P, E9LU63F, E9LU66R, E9LS63F, EXLU65M, B-Safe 35 Elite E9LS55T, E9LS56P, E9LS55U, E9LS66C, E9LS65U, B-Safe 35 Travel Systems S914900, S915400, S915200, S921900, S01635200. Problem 1: car seat handle can crack and break allowing seat to fall unexpectedly, posing risk of injury to child. STOP carrying car seat by handle until repaired. Visit: www.bsafe35recall.com to register and receive free repair kit. Previously registered products will automatically receive kit. Problem 2: made 11/1/15-5/31/17 Models: E1A183F, E1A185M, E1A185P, E1A186R, E1A203F, E1A205M, E1A205P, E1A206X, E1A206Z, E1A207E, E9LU65V, E9LU66X, E9LU66Z, E9L67D, E9LU67E, EXA185M, S02063600, S02063700, S03803400, S03803500, S03803700, S03803800, S03803900, S04144400, S04144500, S04144600, S04145000, S04402800, S04884200, S04884300, S04975600, S04978900, S05260200, S06020300, S06020400, S06020500, S06020600, S06020700, S06020800, S06020900, S06147100, S921800 Center tab on chest clip marked 'ABS' may break, causing choking hazard. Continue to safely use car seat after removing chest clip or monitoring center tab until replaced. Visit: www.bsafe35clip.com or 833-474-7016 for replacement chest clip marked "PC".

B-Safe 35 Elite made 11/1/15-5/31/17 Models: E1A215T, E1A215U, E1A216P, E1A221Q, E1A225C, E1A225U, E1A226L, E9LS51Q, E9LS56C, E9LS56L, E9LS57F, E9LS57G, E9LS57H, EXA216L, S01298600, S02063800, S02063900, S02064000, S04281200, S04281300, S04628500, S06018800, S06020000, S06020200, S923700 Problem: Center tab on chest clip marked 'ABS' may break, causing choking hazard. Continue to safely use car seat after removing chest clip or monitoring center tab until replaced. Visit: www.bsafe35clip.com or 833-474-7016 for replacement chest clip marked "PC"

BOB B-Safe35 made 11/1/15-5/31/17 Models: E9LT34A, E9LT34C, E9LT35X, EXLT34A Problem: Center tab on chest clip marked 'ABS' may break, causing choking hazard. Continue to safely use car seat after removing chest clip or monitoring center tab until replaced. Visit: www.bsafe35clip.com or 833-474-7016 for replacement chest clip marked "PC".

Convertible Seats

Advocate 70-G3 made 6/1/12-8/31/12 Models E9LJ91A, E9LJ91M, E9LJ91S, E9LJ92E, E9LJ93P, E9LJ93S, E9LK91A, E9LK91A, E9LK91A, E9LK31A, E9LK31Q, E9LK32D, E9LK32Z, E9LK33Q, E9LL11A, E9LL11Q, E9LL12D, E9LL12Z, E9LG81A, E9LG83N, E9LG83P, E9LG83Y, E9LG83Y, E9LL23P, E9LL23

Advocate Click Tight made 8/1/14-7/29/15 Models E9LT95Q, E9LT95Z, E9LT95D, E1A025Q Problem: red harness adjuster button may remain down, allowing harness to loosen. If harness straps remain securely tensioned, continue using seat until receipt of remedy kit. If shoulder straps do not remain in place, do not use seat until fixed. Britax sending all registered owners repair kit. Visit www.BritaxClickTightConvertibleRecall.com or call 1-888-427-4829 option 3 to register seat and request repair kit.

Boulevard Click Tight made 8/1/14-7/29/15 Models E9LT86F, E1A135Q, E9LT86G, E9LT86G, E9LT86A, E9LT86H, E9LT85S, E1A015Q, E1A016A, E1A016H Problem: red harness adjuster button may remain down, allowing harness to loosen. If harness straps remain securely tensioned, continue using seat until receipt of remedy kit. If shoulder straps do not remain in place, do not use seat until fixed. Britax sending all registered owners repair kit. Visit www.BritaxClickTightConvertibleRecall.com or call 1-888-427-4829 option 3 to register seat and request repair kit.

Boulevard Problem #1: 70-G3 made 6/1/12-8/31/12 Models E9LJ91A, E9LJ91M, E9LJ91S, E9LJ92E, E9LJ93P, E9LJ93S, E9LK91A, E9LK91A, E9LK91A, E9LK91A, E9LK91A, E9LK31A, E9LK31A, E9LK31A, E9LK32D, E9LK32D, E9LK32D, E9LK32D, E9LK32D, E9LL12D, E9LJ12D, E9

Marathon Click Tight made 8/1/14-7/29/15 Models E1A116L, E9LT76P, E9LT76N, E9LT76N, E9LT76B, E9LT76B, E9LT76L, E1A006B, E1A005R, EXA116L Problem: red harness adjuster button may remain down, allowing harness to loosen. If harness straps remain securely tensioned, continue using seat until receipt of remedy kit. If shoulder straps do not remain in place, do not use seat until fixed. Britax sending all registered owners repair kit. Visit www.BritaxClickTightConvertibleRecall.com or call 1-888-427-4829 option 3 to register seat and request repair kit.

Pavillion 70-G3 made 6/1/12-8/31/12 Models E9LJ91A, E9LJ91M, E9LJ91S, E9LJ92E, E9LJ93P, E9LJ93S, E9LK91A, E9LK91A, E9LK91A, E9LK31A, E9LK31A, E9LK31D, E9LK32D, E9LK32D, E9LK32D, E9LK33D, E9LL11A, E9LL11D, E9LL12D, E9LL12D, E9LL12D, E9LG83N, E9LG83N, E9LG83P, E9LG83P, E9LG83P, E9LG83P, E9LC3P, E9LL23P, E9LL23

Forward Facing Only Seats

Combination Seats

BUBBLEBUM (No Recalls) 7380 Sandlake Road, Suite 500, Orlando, FL 32819, 800-969-6586, www.bubblebum.co/us

(10 1100 all 1100 all

CARES (No Recalls) 800-299-6249 www.kidsflysafe.com

CARFOLDIO (No Recalls) www.mifold.com

CHICCO (No Recalls) 1826 William Penn Way, Lancaster, PA 17601, 877-424-4226, www.chiccousa.com

CLEK (last recall 5/21/21) 12 Upjohn Rd. Suite 1, Toronto, ON M3B2V9 866-656-2462 www.clekinc.com

Rear-Facing Only

Liing made before 9/15/20 model LG19U1

Liingo made before 9/15/20 model LGO20U1

Problem #1: Small piece from canopy support may break off presenting choking hazard. Problem #2: made before 2/22/21 Labels on seat cover and insert may detach causing choking hazard. Contact: 866-656-2462 for replacement parts.

Convertible Seats

Foonf made before 5/21/21 model FO12 through FO19

Filo made before 5/21/21 model FL15 through FL19

Problem: Loose pieces of foam cushion under seat can present choking hazard. Call: 866-656-2462 for molded plastic insert.

COLUMBIA MEDICAL (No Recalls) 13577 Larwin Circle, Santa Fe Springs, CA 90670, 800-454-6612, www.columbiamedical.com

COMBI USA, INC. (last recall 9/29/21) 3520 Westinghouse Blvd, Ste B, Charlotte, NC 28273, 800-992-6624, www.combiusa.com

Rear-Facing Only

BabyRide Problem: made 5/1/16-8/31/19 model 378099 Child seat webbing may fail and not adequately restrain a child during a crash; increasing risk of injury. Remedy is under development. Contact: customerservice@combiusa.com

Convertible Seats

Coccoro Problem 1: made 1/1/2009-6/29/16 Model 8220 Only affects seat's performance when installed forward-facing and secured with vehicle's laponly belt. Excessive force may be transferred to car seat occupant in event of a crash; increasing risk of injury. Call: 888-232-3294 or visit http://registration.combiusa.com/recall for free remedy kit. Problem 2: made 1/6/2009-12/5/2012 embedded plastic button prevents harness strength from meeting minimum breaking strength when tested independently from child restraint. Could affect overall performance of child restraint in a crash. Call: 844-697-1690 or www.combiusa.com for free harness replacement kit. Combi encourages use of seat until remedy kit installed.

Zues 360 made 2/25/2009-5/24/2012 and Zues Turn made 7/15/2007-3/25/2009 Model 8815. Problem: embedded plastic button prevents harness strength from meeting minimum breaking strength when tested independently from child restraint. Could affect overall performance of child restraint in a crash. Call: 844-697-1690 or www.combiusa.com for free harness replacement kit. Combi encourages use of seat until remedy kit installed.

COMPASS (See Tomy International)

CONVAID (no recalls) 888-266-8243 www.convaid.com

COSCO (See Dorel Juvenile Group)

DIONO (last recall 11/30/20) 14810 Puyallup Street, Sumner, WA 98390, 855-GO-DIONO, www.diono.com

Combination, All in One Seats

Radian R100 made 1/3/14-9/5/17 Model 16600, 16000; R120 made 1/3/14-8/30/17 model 16800, 16000; RXT made 11/25/13-9/5/17 model 16900, 16000

Olympia made 4/12/14-3/31/15 Model 30100

Pacifica made 4/12/14-5/13/16 Model 30400, 300000

Rainier made 4/12/14-9/5/17 Model 30300, 300000

Problem: When seat secured with the lap belt without using top tether, the seat may not adequately protect child and increase risk of chest injury in a crash. Diono will provide remedy kit, updated instruction manual, energy absorbing pad, new chest clip starting 11/22/17. **Call**: 855-463-4666.

Booster Seats

Cambria 2 made 9/5/20-11/30/20 Model 31200-US-01, 31201-US-01, 31202-US-01. Problem: Crack between headrest and backrest may occur in a crash; increasing risk of injury. Diono will replace backrest and headrest assembly. Call: 855-463-4666.

DOONA (See Simple Parenting)

DOREL JUVENILE GROUP (last recall 8/24/2021) 2525 State Street, Columbia, IN 47201, 800-544-1108, www.djgusa.com (Cosco/ Eddie Bauer/Maxi-Cosi/ Quinny/Safety 1st)

Car Beds

Rear-Facing Only Seats

Comfy Carry made 5/1/11-4/25/12 Model IC123 FSM. Problem: Some seats were sold without lower LATCH attachment strap. Call: 877-416-8111 for replacement base with LATCH. Until new base is received consumers should use the seat installed with a seat belt.

OnBoard 35 made 5/1/11-4/25/12 Model IC124 FSM. Problem: Some seats were sold without lower LATCH attachment strap. Call: 877-416-8111 for replacement base with LATCH. Until new base is received consumers should use the seat installed with a seat belt.

Convertible

Maxi Cosi Pria 85 Problem: If installed forward-facing with only the lap belt, child has increased risk of injury in the event of a crash. No remedy or schedule for recall notification at this time. Call: 877-657-9546.

3-in-1 Seats

Booster Seats

Babideal Storm by Dorel China America **made 2/28/19 Model BC901BPXL Problem:** label on fabric missing safety warnings and instructions. DCA to notify registered owners and provide replacement fabric cover or **call** 877-657-9546 or **text** 812-373-6673.

EDDIE BAUER (See Dorel)

ETAC (incl. Convaid, R82) 844-876-6245 www,etac.us.com

Convertible

R82 Quokka made May 2019 CONSUMER ADVISORY Problem: some arrive with broken RF belt guide. Call: 844-876-6245 for free kit.

EVENFLO COMPANY INC. (last recall 2/9/2016) 1801 Commerce Drive, Piqua, OH 45356, 800-543-8954 www.evenflo.com

Rear-Facing Only Seats

Embrace35 made 12/1/2011-5/31/2013 Model 30711365, 31511040, 31511323, 31511400, 3151198, 3151953, 31521138, 46811205, 46811237, 48111200, 48111215, 48111215, 48111218, 48111234, 48111235, 48111235, 48111462, 48411391, 48411391D, 48411392, 48411504, 48411504D, 52911307A, 52921040, 55311138, 55311238, 55311292 Problem: harness buckle may become difficult to unlatch over time, making it challenging to remove child from seat. NOTE: not all models in this list are impacted. Call 800-490-7591 or go to www.embracebuckle.evenflo.com to determine if your seat is affected and obtain a free remedy kit.

Convertible Seats

Momentum (65, 65 LX, 65 DLX) made 3/4/2013 - 8/26/2013 Models beginning with "385".

SureRide DLX made 6/20/2012 - 10/17/2013 Models beginning with "371".

Titan 65 made 6/20/2012 - 10/17/2013 Models beginning with "371".

Problem: May experience difficulty unlatching harness buckle; buckle may become stuck – increasing risk of injury if prompt exit of vehicle is required. Does not affect performance of car seat or buckle to restrain the child. **Call: 800-490-7591 for new buckle or order online at www.buckle.evenflo.com**

Combination, All in One Seats

Chase, Chase LX, Chase Select made 6/12/2012 – 10/3/2013 Models beginning with "306"; and Chase LX, Chase DLX made 8/23/2011 – 3/3/2014 Models beginning with "329". Problem: May experience difficulty unlatching harness buckle; buckle may become stuck – increasing risk of injury if prompt exit of vehicle is required. Does not affect performance of car seat or buckle to restrain the child. Call: 800-490-7591 for new buckle or order online at www.buckle.evenflo.com

Evolve 3-in-1 made 2/26/15 – 2/9/16 model number 34411700 AND made 5/27/15 – 2/9/16 model number 34411741. Problem when used with harness, child may access button and loosen harness and increase risk of injury. Do not use seat with harness if child is loosening harness. Call: 800-233-5921 or www.evolve.evenflo.com for remedy kit.

Maestro and Maestro Performance made 8/22/2011 – 10/17/2013 Model number begins with "310". Problem #1: May experience difficulty unlatching harness buckle; buckle may become stuck – increasing risk of injury if prompt exit of vehicle is required. Does not affect performance of car seat or buckle to restrain the child. Call: 800-490-7591 for new buckle or order online at www.buckle.evenflo.com

Secure Kid (LX, DLX, 100, 300 and 400) made 12/13/2011 – 3/3/2014 Models beginning with "308". Problem: May experience difficulty unlatching harness buckle; buckle may become stuck – increasing risk of injury if prompt exit of vehicle is required. Does not affect performance of car seat or buckle to restrain the child. Call: 800-490-7591 for new buckle or order online at www.buckle.evenflo.com

Snugli Booster made 12/13/2011 – 3/3/2014 Models beginning with "308". Problem: May experience difficulty unlatching harness buckle; buckle may become stuck – increasing risk of injury if prompt exit of vehicle is required. Does not affect performance of car seat or buckle to restrain the child. Call: 800-490-7591 for new buckle or order online at www.buckle.evenflo.com

Snugli All-in-One made 10/2/2012 - 8/26/2013 Models beginning with "345" or "346".

Symphony (65, 65 E3, LX and DLX) made 10/2/2012 - 8/26/2013 Models beginning with "345" or "346".

Problem: May experience difficulty unlatching harness buckle; buckle may become stuck – increasing risk of injury if prompt exit of vehicle is required. Does not affect performance of car seat or buckle to restrain the child. Call: 800-490-7591 for new buckle or order online at www.buckle.evenflo.com

Transitions 3 in 1, made prior to 1/29/16 Models 34411686, 34411695, 34411029 Problem: Child can access central front adjuster (CFA) resulting in a loose harness and increasing risk of injury. Do not use seat with harness if child is accessing CFA area. Seat may be used safely as booster for child 40 pounds and 43.3 inches. Discontinue use until repaired if child does not meet booster requirements and is accessing CFA area. **Call:** 800-233-5921 or www.transitions.evenflo.com for remedy kit.

Booster Seats

Big Kid Model 30911173AD, 3091967AD, 30911118AD & 30911120D Problem: Small number of seats intended for display were incorrectly shipped to institutional customers. Seats were shipped between 8/6/12-9/18/12. Affected units have a label stating: "DISPLAY ONLY" NOT INTENDED FOR SALE, on the back of headrest. These units meet all crashworthiness standards. Call: 800-233-5921 for instruction manual, registration card, and label.

E-Z-ON PRODUCTS (No Recalls) 605 Commerce Way West, Jupiter, FL 33458, 800-323-6598, www.ezonpro.com
FIRST YEARS, THE (See Tomy International)
GOBOOSTER (No Recalls) 888-327-4336, www.gobooster.com
GOODBABY USA (see Evenflo) 844-543-2020, www.gbchildusa.com

GRACO (last recall 4/5/2016) 150 Oaklands Blvd Exton, PA 19341, 800-345-4109, www.gracobaby.com

Rear-Facing Only Seats

Aprica A30 made 7/1/11 - 4/30/12

Problem: May experience difficulty unlatching harness buckle; buckle may become stuck – increasing risk of injury if prompt exit of vehicle is required. Does not affect performance of car seat or buckle to restrain the child. **Call:** 877-766-7470 for replacement buckle or www.gracobucklerecall.com

SnugRide, SnugRide Classic Connect made 3/1/11 - 5/31/13

SnugRide 30, SnugRide Classic Connect 30 made 7/1/10 - 1/31/13

SnugRide 35, SnugRide Classic Connect 35 made 5/1/11 - 1/31/13

SnugRide Click Connect 40 made 6/1/12 - 12/31/12

Problem #1: May experience difficulty unlatching harness buckle; buckle may become stuck – increasing risk of injury if prompt exit of vehicle is required. Does not affect performance of car seat or buckle to restrain the child. **Call:** 877-766-7470 for replacement buckle or www.gracobucklerecall.com

Convertible Seats

Classic Ride 50 made 10/1/2011 – 9/30/2013 Problem #1: May experience difficulty unlatching harness buckle; buckle may become stuck – increasing risk of injury if prompt exit of vehicle is required. Does not affect performance of car seat or buckle to restrain the child. Call: 800-345-4109 for replacement buckle Problem #2: Model 1812930 3/1/2014 - 2/28/2015 Missing information on location of manufacturer's instructions. Call: 800-345-4109 for replacement label. consumerservices@gracobaby.com

Comfort Sport made 10/1/2010 – 9/30/2013 Problem #1: May experience difficulty unlatching harness buckle; buckle may become stuck – increasing risk of injury if prompt exit of vehicle is required. Does not affect performance of car seat or buckle to restrain the child. Problem #2: Made 3/1/2014 - 2/28/2015 Model 1794333, 1813040 Missing information on location of manufacturer's instructions. Call: 800-345-4109 for replacement buckle or label or consumerservices@gracobaby.com

Extend2Fit made 11/27/2015 – 1/20/2016 Model 1954477 Problem: Recline label affixed incorrectly, may result in wrong angle position. Seat should have all English labels on one side; and Spanish on other. If labels are mixed languages on one side, obtain new label. Call: 800-345-4109. Head Wise 70 with Safety Surround made 1/1/2012 – 7/31/2013; and 8/3/2013 Problem: May experience difficulty unlatching harness buckle; buckle may become stuck – increasing risk of injury if prompt exit of vehicle is required. Does not affect performance of car seat or buckle to restrain the child. Call: 800-345-4109 for replacement buckle or consumerservices@gracobaby.com

My Ride 65, My Ride 65 with Safety Surround made 4/1/2009 – 7/31/2013; and 9/30/2013 Problem 1: May experience difficulty unlatching harness buckle; buckle may become stuck – increasing risk of injury if prompt exit of vehicle is required. Does not affect performance of car seat or buckle to restrain the child. Problem 2: must have webbing tag code 2014/06 AND model 1794334 (made 5/20/14 - 7/15/14), 1813015 (7/3/14 - 7/24/14), 1813074 (6/20/14 - 7/27/14), 1853478 (7/11/14 - 7/27/14), 1871689 (7/5/14 - 7/24/14), 1872691 (5/16/14 - 8/1/14), 1877535 (5/26/14 - 7/27/14), 1908152 (7/23/14 - 7/27/14) Harness webbing doesn't meet federal requirements. May not adequately restraint child resulting in increased risk of injury in a crash. Call: 800-345-4109 for replacement parts or consumerservices@gracobaby.com

My Ride 70 made 5/1/2012 - 7/31/2013

My Size 70 made 1/1/2012 – 7/31/2013; and 8/3/2013 Problem: May experience difficulty unlatching harness buckle; buckle may become stuck – increasing risk of injury if prompt exit of vehicle is required. Does not affect performance of car seat or buckle to restrain the child. Call: 800-345-4109 for replacement buckle or consumerservices@gracobaby.com

Ready Ride made 10/1/2010 – 9/30/2013 Problem #1: May experience difficulty unlatching harness buckle; buckle may become stuck – increasing risk of injury if prompt exit of vehicle is required. Does not affect performance of car seat or buckle to restrain the child. Call: 800-345-4109 for replacement buckle or consumerservices@gracobaby.com Problem #2: Made 3/1/2014-2/28/2015 Model 1924519, 1924520 Missing information on location of manufacturer's instructions. Call: 800-345-4109 for replacement label.

Size4Me 70 made 1/1/2012 – 7/31/2013; and 8/3/2013 Problem: May experience difficulty unlatching harness buckle; buckle may become stuck – increasing risk of injury if prompt exit of vehicle is required. Does not affect performance of car seat or buckle to restrain the child. **Call:** 800-345-4109 for replacement buckle or consumerservices@gracobaby.com

Smart Seat and Smart Seat with Safety Surround made 12/1/2010 - 9/30/2013; and 10/9/2013, 12/25/2013, 1/10/2014

Problem: May experience difficulty unlatching harness buckle; buckle may become stuck – increasing risk of injury if prompt exit of vehicle is required. Does not affect performance of car seat or buckle to restrain the child. **Call:** 800-345-4109 for replacement buckle or consumerservices@gracobaby.com

3-in-1 Seats

Milestone made 7/9/15 - 10/9/15 models 1910130, 1923980, 1926538, 1926539 Problem: Labels do not have required wording about how to install seat with LATCH or seat belt per FMVSS 213. Recall does not affect safety performance. Registered owners will be sent a new label or Call: 800-345-4109

Combination Seats

Argos 70, Argos 70 Elite made 5/1/2011 - 7/31/2013

Nautilus 3-in-1, Nautilus Elite, Nautilus Plus made 10/1/2007 - 7/31/2013; and 8/19/2013

Problem: May experience difficulty unlatching harness buckle; buckle may become stuck – increasing risk of injury if prompt exit of vehicle is required. Does not affect performance of car seat or buckle to restrain the child. **Call:** 800-345-4109 for replacement buckle or consumerservices@gracobaby.com

Booster Seats

Turbo model 1963973 made 3/8/16-4/2/16; 1963974 made 12/22/15-3/30/16; 1963975 made 12/22/15-3/17/16; 1963976 made 2/17/16-3/24/16; 1967886 made 1/13/16-4/5/16; 1975173 made 3/29/16. Problem: Owner's manual left out instruction to secure booster seat when not in use. This does not affect performance of seat in a crash. Obtain missing printed instructions by calling 800-345-4109

not affect performance of seat in a crash. Obtain missing printed instructions by calling 800-345-4109.

HARMONY JUVENILE PRODUCTS (last recall 6/24/17) 1600 53rd Street, North Bergen, NJ 07047, 877-306-1001, www.harmonyjuvenile.com

Booster Seats
Big Boost Deluxe made 11/1/15 – 6/24/17 Problem: In a crash the seat belt may cause excessive force to child's chest, increasing risk of injury. Remedy is under development. Call: 877-306-1001

HAUCK/ICOO (No Recalls) 905-455-5888 www.hiccapop.com

HICCAPOP (No Recalls) 833-442-2266 www.hiccapop.com

IMMI (See Safe Guard) 317-896-6612 www.imminet.com

INSPIREDBYDRIVE formerly Columbia Medical (No Recalls) 800-454-6612 www.inspiredbydrive.com

JANE' (No Recalls) 415-824-1237 www.janeus.com

JEFFCO FIBRES (No Recalls) 508-673-1001 www.jeffcofibres.com

JJ COLE (see Tomy)
KIDDY (last recall 5/1/13) 685 Dividend Drive, Suite 100, Peachtree City, GA 30269, 855-925-4339, www.kiddyusa.com
Combination Seats World Plus model 51 100 WP made 2/1/12-10/5/13 Problem: When using seat with shield, buckle/tongue may not fully engage; not adequately restraining child in a crash. Call: 855-925-4339 to arrange for return of seat and reimbursement of purchase price.
KIDS EMBRACE (no recalls) 866-947-3287 www.kidsembrace.com
KIDS II aka Ingenuity (No Recalls) 770-551-0442 www.kidsii.com
LAMAZE (See Tomy International)
LAROCHE BROTHERS (see Jeffco Fibres)
LEARNING CURVE (See Tomy International)
LIL FAN (no recalls) 317-804-9160 www.lilfan.com
LILLY GOLD (see Triple Play)
LITTLE TIKES (No Recalls) 800-321-0183 www.littletikes.com
MAXI-COSI (See Dorel Juvenile Group)
MERRITT MANUFACTURING (Last recall 10/24/19) PO Box 17152, Indianapolis, IN 46217, 317-409-0148, www.eztether.com Car bed Angel Guard Angel Ride car bed made between 8/8/19 – 10/24/19. Problem: restraint harness may not have been properly sewn; may not restrain the bed occupant properly. Call: 317-409-0146 for free replacement harness.
MIA MODA, INC./LARADO 1 Meridian Blvd, Wyomissing, PA, 19610, 866-MIA-MODA, www.miamodainc.com
MIFOLD (see Carfoldio)
NANIA (See BabyRide under Combi)
NUNA (No recalls) 70 Thousand Oaks Blvd., Morgantown, PA 19543, 610-913-5100, www.nunababy.com
ORBIT BABY (last recall 7/20/2013) 5437 Central Ave, Ste 10, Newark, CA 94560, 877-ORB-BABY, www.orbitbaby.com
Rear-Facing Only Seat Orbit Baby Car Seat Bases Problem #1: G2 bases made between 3/20/13 - 7/20/13. Model ORB822000. Batch Number A0840, A0860 or A0880 StrongArm Knob may detach or spin without tightening the base preventing proper installation. Register seat at www.orbitbaby.com , call 877-ORBBAE to receive free StrongArm Repair Kit. If seat is not already tightly installed, use the car seat without the base until fixed. Problem #2: All Orbit Baby Bases made pre- 2/2008. Base must be upgraded for use w/ Toddler Car Seat. Call: 877-ORBBABY or visit www.orbitbaby.com. To receive new bas w/ green circular seal, Toddler seat & Base must both be registered.
PEG-PÉREGO 3625 Independence Dr, Fort Wayne, IN 46808, 800-671-1701, www.pegperego.com
PHIL & TEDS (no recalls) 800-839-4985 www.philandteds.com
PORCHE (Contact Britax)
R82 (see Etac)
RECARO (last rocall 6/9/2015), 4120 Lucilla Lano Lano, Auburn Hills, MI 48226, 248, 264, 2818, www.rocaroura.com

Convertible Seats

ProRIDE model 332.01 made 4/9/10-6/9/15 in all colors (AK21, KAEC, KAEG, KK91, MC11, MJ15, QA56, QA9N, QQ11, QQ14, and QQ95) Problem: top tether anchorage may detach from the child restraint in a crash increasing risk of injury to child or vehicle occupants. Recaro will notify/send registered owners repair kit. Call: 866-628-4750 or email recarorecall@m-s-s.com for free retrofit kit.

Performance RIDE model 333.01 made 1/15/13-6/9/15 in all colors (CHIL, HABB, HAZE, JEBB, JETT, KNGT, MABB, MARI, MNGT, PLUM, PLBB,

Performance RIDE model 333.01 made 1/15/13-6/9/15 in all colors (CHIL, HABB, HAZE, JEBB, JETT, KNGT, MABB, MARI, MNGT, PLUM, PLBB, REBB, SLBB, REDD, ROBB, ROSE, SABB, SAPH, SLTE, VIBB, VIBE). Problem: top tether anchorage may detach from the child restraint in a crash increasing risk of injury to child or vehicle occupants. Recaro will notify/send registered owners repair kit. Call: 866-628-4750 or email recarorecall@m-s-s.com for free retrofit kit.

Combination Seats

ProSport model 385 made 6/16/10-1/31/13 Problem: when installed with lower anchors and no tether, the child's head can move too far forward, increasing risk of injury. For child weighing 40 or more pounds, seat belt must be used for installation. Call: 888-973-2276 to obtain label and new instructions.

SAFE TRAFFIC SYSTEM INC. (No Recalls) 3343 W Eastwood Ave, Chicago, IL 60625, 847-329-8111, www.safetrafficsystem.com

SAFEGUARD (No Recalls) 18881 US 31 North, Westfield, IN 46074, 800-586-7839, www.safeguardseat.com

SAFELINE KIDS (See Tripleplay)

SAFETY 1ST (See Dorel)

SENTRY BABY PRODUCTS (No Recalls) 719-212-6016 www.sentrybabyproducts.com

SIMPLE PARENTING (no recalls) 862-240-1755 http://simpleparenting.co

SNUGLI (See Evenflo) 800-374-3603 <u>www.snugli.com</u>

All in One

Snugli All in One models beginning "346" made 10/2/12 -8/26/13 Problem: Harness buckle could be difficult to release in emergency. Call: 800-490-7591

Booster

Snugli Booster models beginning "308" made 12/13/11-3/3/14 Problem: Harness buckle could be difficult to release in emergency. Call: 800-490-7591

SNUG SEAT (see Etac)

SUMMER INFANT (No Recalls) 800-268-6237, www.summerinfant.com

TEAM-TEX AMERICA (see Combi BabyRide)

THOMASHILFEN (No Recalls) 866-870-2122, www.thomashilfen.com

TOMY INTERNATIONAL (No Recalls) 800-704-8697, www.tomy.com

TRIPLE PLAY PRODUCTS (No Recalls) 800-829-1625, www.tripleplayproducts.com

UPPA BABY (No Recalls) 60 Sharp Street, Hingham, MA 02043 781-413-3030, www.uppababy.com

URBINI (see Goodbaby)

WAYB (last recall 8/23/19) help@wayb.com, 888-924-9292,https://wayb.com

Pico child restraints made 2/1/19-8/23/19 Problem: headrest support tubes can break, increasing risk of injury. Plan for replacement is in development. Call: 888-924-9292.